

1. 4 dowels are installed in the bottom.
2. The bottom is attached to the back panel using 4 confirmat screws, 7 × 50 mm.
3. The low front panel is attached to the bottom using 4 confirmat screws, 7 × 50 mm.
4. The side panels are attached to the bottom using 6 confirmat screws, 7 × 50 mm.
5. The fixed top is attached to the side panels using 4 confirmat screws, 7 × 40 mm. The back panel is attached using 4 countersunk screws, 35 × 30 mm.
6. The 4 legs are attached using 12 confirmat screws, 7 × 50 mm, and 8 confirmat screws, 7 × 30 mm. The screws in the back panel and low front panel are installed first (the long 50 mm screws). Short screws are used in the side panels, except where the opening front panel is attached.
7. The sliding bolts and hinges are attached to the opening front panel using countersunk screws, 3.5 × 15 mm. A through bolt is installed through each hinge.
8. The opening lid is attached using 4 hinges.
9. The hasp is attached using screws



INCLUDED

- 4 dowels, 78 × 35 mm
- 26 confirmat screws, 7 × 50 mm
- 8 confirmat screws, 7 × 30 mm
- 4 confirmat screws, 7 × 40 mm for the fixed top
- 4 countersunk screws, 35 × 30 mm for the back panel
- 25 countersunk screws, 35 × 15 mm for hinges and hasp
- 8 countersunk screws, 3 × 15 mm for sliding bolts
- 4 through bolts, 5 × 20 mm
- 4 washers, 5 mm
- 4 lock nuts, 5 mm
- 2 sliding bolts
- 1 hasp
- 4 hinges (large boxes: 6 hinges)
- 1 assembly tool

**CONFIRMAT
SCRWAS**



**COUNTERSUNK
SCRWAS**

