

Serving Trolley

INCLUDED FOR ASSEMBLY:

- 24 dowels, 7.8 × 35 mm
- 18 confirmat screws, 7 × 50 mm
- 6 screws, 3.5 × 30 mm
- 4 castors
- 16 screws, 5.0 × 16 mm

ASSEMBLY:

- Attach the end panels to the three boards using dowels and 7 × 50 mm confirmat screws.
- At the same time as assembling the end panels, insert the supplied battens. The battens are screwed in from underneath in the centre using 3.5 × 30 mm screws.
- Finally, attach the four castors at the bottom using 5.0 × 16 mm screws.

