





8846W

Reading Nook – Pitched Roof – On Wheels




INCLUDED

CONFIRMAT SCREW
10x50mm



48x

WHEEL WITH BRAKE
D75mm




4x

DOWEL
10x35mm



36x

WHEEL WITHOUT BRAKE
D75mm



1x

DOWEL
10x20mm



10x

WHEEL SCREW
45x15mm




20x

1

CONFIRMAT SCREW
10x50mm


DOWEL
10x35mm



2

CONFIRMAT SCREW
10x50mm


DOWEL
10x35mm



3

CONFIRMAT SCREW
10x50mm


DOWEL
10x35mm



4

CONFIRMAT SCREW
10x50mm

DOWEL
10x35mm




5

WHEEL WITH BRAKE
D75mm

WHEEL WITHOUT BRAKE
D75mm


WHEEL SCREW
45x15mm




6

CONFIRMAT SCREW
10x50mm

DOWEL
10x20mm





TIGHTENING

One Wood Furniture recommends tightening the assembly screws. Check and retighten the furniture 14 days after the initial assembly, as the materials may settle during use.

It is also recommended to check and retighten the assembly screws after approximately 6 months.

SEE ALSO OUR OTHER READING NOOKS WITH STORAGE





– TRYGGE BØRN LEGER BEDST



onewood.dk/en



+45 62 27 19 30



Info@onewood.dk