

Fantasy Table

REPLACEMENT OF GLASS/LIGHT

1. Remove the confirmat screws on the sides and bottom of the table facing the largest glass section, so that the spacer between the top and bottom panel of the table is loosened. Remove the spacer so that you can see up underneath the lower tabletop (as on the front side facing the two glass panels).
2. Then loosen 4 screws on both sides of the lower tabletop. See approximate marking. A very small screwdriver is required
3. Lift the top panel and replace the glass/light. Reinstall all screws.

